


VRX 1825 Vane Rotary Actuators 2-1/2 inch (64 mm) Bore


Models: 1825-0110, 1825-0111, 1825-0112,
1825-0113, 1825-0114, 1825-0115

100° Rotation, Dual Vane



MODEL NUMBER	ROTATION	VANE / STATOR	SHAFTS AVAILABLE	OPTION
1825-0113	280°	Single	Single	
1825-0112	280°	Single	Dual	
1825-0111	100°	Dual	Single	
1825-0110	100°	Dual	Dual	
1825-0115	280°	Single	Single	Adjustable Stops
1825-0114	100°	Dual	Single	Adjustable Stops

280° Rotation, Single Vane



ITEM	PART NO.	DESCRIPTION	100°		280°		
			1825-0110	1825-0114	1825-0111	1825-0112	1825-0115
1	18251128	FLAT HEAD CAP SCREW	8	8	8	8	8
2	1825-1125	SHOULDER NUT	8	8	8	8	8
3	1825-1106	BEARING COVER	2	2	2	2	2
4	1825-1107	BALL BEARING	2	2	2	2	2
5	1825-9035	HEAD KIT, Dual Vane	2	2	-	-	-
	1825-9036	HEAD KIT, Single Vane	-	-	1	1	-
	1825-9037	HEAD KIT, Single Vane	-	-	1	1	-
6	1001-1131	O-RING	2	2	2	2	2
7	1825-1103	O-RING	2	2	2	2	2
8	1825-9053	STATOR	2	2	1	1	1
9	1825-9052	ROTOR, Dual Vane, Dual Shaft	1	-	-	-	-
	1825-9069	ROTOR, Dual Vane, Single Shaft	-	1	-	-	-
	1825-9061	ROTOR, Single Vane, Dual Shaft	-	-	1	-	-
	1825-9059	ROTOR, Single Vane, Single Shaft	-	-	-	1	-
10	1825-1145	TUBE	1	1	1	1	1
11	1825-1118	TIE ROD	4	4	4	4	4

Pneumatic Service: The VRX actuator should be operated with 100 PSI maximum pneumatic service lubricated with a non-detergent SAE 30 weight oil.

Axial Loading: Heavy end thrust loading of the actuator shaft is not recommended. Use an isolating coupling which takes the load and does not distribute it to the actuator shaft.

Internal Stops: Do not use internal stops to stop rotation except with loads whose combined weight and speed do not generate more than 0.70 inch-pounds (0.08 Newton-meters) of kinetic energy. Backlash (lost motion) between the shaft and load should be avoided.

External Stops: External stops are recommended for higher inertia loads to avoid vane and stator damage. Stops should be securely mounted to machine framework.

DISASSEMBLY NOTE:

VRX Ball Bearings (#4) are installed using retaining compound. Additional force may be required to separate the Ball Bearings (#4) during disassembly. Also note that the Ball Bearing (#4) may stay attached to the Rotor (#9) or to the Head (#5).

ASSEMBLY INSTRUCTIONS – 100° ACTUATOR

1. Use Teflon®-additive grease when lubrication is required.
2. Lubricate and install small O-Ring (#6) into groove in center bore of each Head (#5).
3. Lubricate and install large O-Ring (#7) into groove on face of each Head (#5).
4. Lubricate rubber surfaces and insert two [2] Stators (#8) into one Head (#5) by aligning the dowel pins with the holes in the Head (#5).
5. Lubricate rubber surfaces and insert Rotor (#9) between the two [2] Stators (#8) and into the center bore of the Head (#5).
6. Lightly lubricate the inside diameter of the Tube (#10) and slide over the two [2] Stators (#8) and Rotor (#9) until engaging the Head (#5).
7. Align and install the other Head (#5) onto the dowel pins of the two [2] Stators (#8) and the shaft of the Rotor (#9) through the center bore. NOTE: Assemble with the ports on the same side of both Heads (#5).
8. Thread four [4] Shoulder Nuts (#2) half way onto each of the four [4] Tie Rods (#11) then insert each Tie Rod (#11) through the holes in both Heads (#5).
9. Thread the remaining four [4] Shoulder Nuts (#2) onto the four [4] Tie Rods (#11). Shoulder Nuts (#2) must be inserted into Head (#5) then threaded onto the Tie Rod (#11).
10. Use a criss-cross pattern to evenly tighten each of the Shoulder Nuts (#2). Torque Shoulder Nuts (#2) to 60 in-lbs (6.8 N-m).

11. Use retaining compound on the outside and inside diameter of each of the two [2] Ball Bearings (#4) then slide Ball Bearing (#4) over and into the bore of each Head (#5). NOTE: The Ball Bearing (#4) will bottom out on the Rotor (#9) shaft not the bore in the Head (#5).
12. Install Bearing Cover (#3) onto each of the Heads (#5) using Flat Head Screws (#1).

ASSEMBLY INSTRUCTIONS – 280° ACTUATOR


1. Use Teflon®-additive grease when lubrication is required.
2. Lubricate and install small O-Ring (#6) into groove in center bore of each Head (#5).
3. Lubricate and install large O-Ring (#7) into groove on face of each Head (#5).
4. Lubricate rubber surfaces and insert Stator (#8) into Head (#5) by aligning the dowel pins with the holes in the Head (#5).
5. Lubricate rubber surfaces and insert Rotor (#9) next to the Stator (#8) and through the center bore of the Head (#5). Rotate Rotor (#9) so vane is across from the Stator (#8).
6. Lightly lubricate the inside diameter of the Tube (#10) and slide over the Stator (#8) and Rotor (#9) until engaging the Head (#5).
7. Align and install the other Head (#5) onto the dowel pins of the Stator (#8) and the shaft of the Rotor (#9) through the center bore. NOTE: Assemble with the ports on the same side of both Heads (#5).
8. Thread four [4] Shoulder Nuts (#2) half way onto each the four [4] Tie Rods (#11) then insert each Tie Rod (#11) through the holes in both Heads (#5).

9. Thread the remaining four [4] Shoulder Nuts (#2) onto the four [4] Tie Rods (#11). Shoulder Nuts (#2) must be inserted into Head (#5) then threaded onto Tie Rod (#11).
10. Use a criss-cross pattern to evenly tighten each of the Shoulder Nuts (#2). Torque Shoulder Nuts (#2) to 60 in-lbs (6.8 N-m).
11. Use retaining compound on the outside and inside diameter of the two [2] Ball Bearings (#4) then slide Ball Bearing (#4) over and into the bore of each Head (#5). NOTE: The Ball Bearing (#4) will bottom out on the Rotor (#9) shaft not the bore in the Head (#5).

12. Install Bearing Cover (#3) onto each of the Heads (#5) using Flat Head Screws (#1).

Teflon® is a registered trademark of the E.I.DuPont de Nemours Co., www.dupont.com

Adjustable Stop Assembly



ITEM	PART NO.	DESCRIPTION	QTY.
1	1825-1035	CAP	1
2	1001-1153	SOCKET HEAD CAP SCREW	4
3	1825-1032	LABEL	1
4	1825-1027	OUTSIDE PLATE	1
5	1825-1030	STOP RINGS	2
6	1825-1033	SQUARE KEY	1
7	1825-1034	SET SCREW	2
8	1825-1026	PADDLE	1
9	1825-1028	INSIDE PLATE	1
10	1825-1011	BRONZE BUSHING	1



3800 County Road 116, Hamel, MN 55340
 http://www.Tolomatic.com • Email: Help@Tolomatic.com
 Phone: (763) 478-8000 • Fax: (763) 478-8080 • Toll Free: 1-800-328-2174



Information furnished is believed to be accurate and reliable. However, Tolomatic assumes no responsibility for its use or for any errors that may appear in this document. Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated motion products without notice. Information in this document is subject to change without notice.